


AC10304



AC10304 parts list			
No.	Item no.	Qty	Parts
1	H100022001	12	Screw
2	A100022002	12	Flat washer
3	H100022002	2	Cylinder Head
4	H100022003	2	Seal
5	A100022019	4	O-Ring
6	A100022018	2	Gas-guide Tube
7	E100022005	2	Screw
8	A100022005	2	Limit Range Implement
9	A100022006	4	Valve Block
10	H100022004	2	Valve Board
11	A100022009	2	Valve plate clamp
12	H100022005	2	Screw
13	H100022006	2	O-Ring
14	H100022007	2	Cylinder
15	H100022008	2	Screw
16	H100022009	2	Valve Board
17	H100022010	2	Piston Cup
18	H100022011	2	Connecting Rod
19	H100022012	2	Wind Scooper
20	H100022013	2	circlip for shaft
21	H100022014	1	B Fan
22	A100022038	4	Shock Pad
23	H100022015	4	Screw
24	H100022016	1	Left Crankcase
25	H100022017	2	Screw
26	H100022018	2	Bearing
27	H100022019	1	Motor Rator
28	H100022020	4	Nut
29	H100022021	1	Motor Staotr
30	A100022033	4	Cushion
31	H100022022	4	Bolt
32	A100022039	4	Nut
33	A100022045	2	Power Cord Buckle
34	H100022023	1	Right Crankcase
35	H100022024	4	Screw
36	H100022025	2	Bearing
37	H100022026	2	Crank
38	H100022027	1	A Fan
39	A100022036	1	Air Filter
40	A100022037	1	Hush Pipe
41	H100022028	1	Horizontal Tank
42	H100022029	1	Regulator Valve
43	H100022030	2	Pressure Gauge
44	H100022031	2	Elbow
45	E100022072	1	Quick Connect
46	E100022069	2	Screw
47	H100022032	1	Nylon Pipe

